

RHMV Stocking Parts List

Stocking Parts: Electrical Group

No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RHMV 24 17 SE AC JA	RHMV 24 21 HE AC JA	RHMV 24 21 UE AC JA	RHMV 24 21 ME AC JA
17	Stk	Transformer	46-101905-01	46-101905-01	46-101905-01	46-101905-01
18	Stk	Control Board	47-105415-01	47-105415-01	47-105415-02	47-105415-01
No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RHMV 36 17 SE AC JA	RHMV 60 21 SE AC JA	RHMV 60 24 ME AC JA	
17	Stk	Transformer	46-101905-01	46-101905-01	46-101905-01	
18	Stk	Control Board	47-105415-01	47-105415-01	47-105415-01	
No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RHMV 24 21 MN AC JA	RHMV 30 21 SN AC JA	RHMV 36 21 MN AC JA	RHMV 48 21 SN AC JA
17	Stk	Transformer	46-101905-01	46-101905-01	46-101905-01	46-101905-01
18	Stk	Control Board Kit (Includes Control and Communication Boards)	AS-107913-81	AS-107913-82	AS-107913-83	AS-107913-84

Stocking Parts: Blower Group

No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RHMV 24 17 SE AC JA	RHMV 24 21 HE AC JA	RHMV 24 21 UE AC JA	RHMV 24 21 ME AC JA
15	Stk	Blower Assembly (Includes items 16-22) before W0417	AS-101885-25	AS-101885-29	AS-101885-26	AS-101885-25
15	Stk	Blower Assembly (Includes items 16-22) on or after W0417	AS-101885-25	AS-101885-28	AS-101885-26	AS-101885-25
	Stk	Blower Wheel (before W0417)	703014	703023	703023	703014
	Stk	Blower Wheel (on or after W0417)	703014	703014	703023	703014
22	Stk	Blower Motor	51-104388-01	51-104389-01	51-102603-01	51-104388-01
No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RHMV 36 17 SE AC JA	RHMV 60 21 SE AC JA	RHMV 60 24 ME AC JA	
15	Stk	Blower Assembly (Includes items 16-22)	AS-101885-28	AS-101885-26	AS-101885-27	
	Stk	Blower Wheel	703014	703023	703015	
22	Stk	Blower Motor	51-104389-01	51-102603-01	51-102603-01	
No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RHMV 24 21 MN AC JA	RHMV 30 21 SN AC JA	RHMV 36 21 MN AC JA	RHMV 48 21 SN AC JA
	Stk	Blower Wheel	703014	703014	703023	703023
22	Stk	Blower Motor	51-102601-01	51-102601-01	51-102603-01	51-102603-01

Stocking Parts: Coil Parts

No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RHMV 24 17 SE AC JA	RHMV 24 21 HE AC JA	RHMV 24 21 UE AC JA	RHMV 24 21 ME AC JA
12		Replacement Coil w/TXV	RCH-2417SEAVUA	RCH-3621MEAVUA	RCH-2421UEAVUA	RCH-2421MEAVUA
		Drain Pan - Vertical	See specified RCH Coil Parts List			
		TXV	See specified RCH Coil Parts List			
No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RHMV 36 17 SE AC JA	RHMV 60 21 SE AC JA	RHMV 60 24 ME AC JA	
12		Replacement Coil w/TXV	RCH-3617SEAVUA	RCH-6021SEAVUA	RCH-6024MEAVUA	

		Drain Pan - Vertical	See specified RCH Coil Parts List			
		TXV	See specified RCH Coil Parts List			
No.	Notes	MODEL	RHMV	RHMV	RHMV	RHMV
		CAPACITY	24	30	36	48
		CABINET SIZE	21	21	21	21
		COIL SIZE/METERING	MN	SN	MN	SN
		MAJOR SERIES/CONTROLS	AC	AC	AC	AC
		VOLTAGE/MINOR SERIES	JA	JA	JA	JA
12		Replacement Coil w/TXV	RCH-3021SNAMUA	RCH-3021SNAMUA	RCH-4821SNAMUA	RCH-4821SNAMUA
		Drain Pan - Vertical	See specified RCH Coil Parts List			
		TXV	See specified RCH Coil Parts List			